


New JIS(JIS C

New JIS(JIS C 1102-1997) Compliance



# Portable Instruments

New JIS(JIS C 1102-1997) Compliance



# Usage Precautions

 Warning: Indicates usage precautions that must be read to ensure the safety of users and the equipment.

## Safety Instructions for Portable Instruments

### 1. Usage environment and conditions

Do not use YOKOGAWA portable instruments in locations such as the following:

- Locations where the ambient temperature is outside the range of 0-40°C
- Locations where relative humidity is outside the range of 30-75%
- Locations subject to vibrations or shock impact
- Locations subject to rain, dripping water, or direct sunlight
- Locations exposed to large amounts of dust, salt, soot, or corrosive gases (sulfurous acid gas, ammonia gas, hydrogen sulfide gas, or other gases that corrode metals or plastics)
- Locations subject to strong external noise or electromagnetic waves
- Locations subject to large amounts of static electricity
- Locations subject to large amounts of high frequencies and waveform distortion (e.g., from inverters or thyristor circuits)

### 2. Wiring

Adhere to the following rules when connecting the wires:

- When connecting an instrument with accessories, first make sure none of the wires are live.
- The connector terminals on the wires should be appropriate for the electricity load and terminal size.
- Connect the wires properly as illustrated in the wiring diagrams of catalogs or on product labels.
- Fasten connector terminals to the proper torque for the size of screw being used.
- Instruments that are combined with current transformers (CT) should be properly connected to the secondary side of the CT. Improper connection may result in a CT failure, burned components, or a fire. When the secondary side of a CT is disconnected, especially while the primary side is powered, the secondary side terminal will carry a high voltage which could result in electrical shock. Therefore, the secondary side should be short-circuited before the instrument is disconnected.

### 3. Usage precautions

- Use the instrument within the rated specifications. Failure to do so can cause the equipment to malfunction or result in a failure.
- While the power is on, do not touch any terminals or open the cover or case.
- The current transformer emits heat while powered, so do not touch it.

### 4. What to do if the equipment functions abnormally or fails

- If you notice abnormal heating, or a strange odor, noises, or smoking or if the equipment seems to have failed, immediately take steps such as cutting off the input. Next, contact your YOKOGAWA sales office.

### 5. Maintaining and checking the equipment

To ensure that your instrument operates properly, perform the following checks on a regular basis:

- Check for damage to the instrument or accessories due to heating or other factors.
- Check for loose attachments or screws (always turn off the power before doing this to ensure safety).
- The instrument covers have been coated with an antistatic agent to block static electricity. Gently wipe dirt off the cover surfaces with a soft, dry cloth. Do not use a wet cloth as this will reduce the effects of the antistatic coating. Do not allow cloths made from synthetic materials to contact the cover for an extended period of time, and do not use benzene, paint thinner, or similar substances. Doing so may cause the cover to become deformed, discolor it, or cause cracking.
- If the indicator reading becomes unstable due to static electricity, coat the front and back of the cover with a commercially available antistatic agent.
- Instrument service life will vary according to usage conditions. In general, however, we recommend replacing the instrument after about 15 years of use.

# Table of Contents

## CONTENTS

Page

**1**

**Portable Instrument (Ammeter and Voltmeter) Selection Guide**

**2**

**Portable DC Ammeters and Voltmeters**

**3**

**Portable AC Ammeters and Voltmeters**

**4**

**Portable High-frequency AC Ammeters and Voltmeters,  
Portable Audio-Frequency Voltmeters**

**5**

**Portable Needle-indicator Frequency Meters**

**6**

**Portable Power Factor Meters**

**7**

**Portable Wattmeters**

**8**

**Miniature Portable Ammeters and Voltmeters**

**9**

**Instrument Transformers**

**10**

**Shunts, External Multipliers, and Carrying Cases**

**11**


**JIS Mark List**

**12**

**Q & A**

# Selection Guide

## Portable Instrument (Ammeter and Voltmeter)



# Portable DC Ammeters and Voltmeters

## 2011, 2012



Models **2011** and **2012** are moving coil type instruments using a taut-band suspension system. The suspension system provides excellent reproducibility without friction, and strong resistance to shock impact. These precision instruments combine a magnetic circuit (sandwich mechanism) that blocks the effects of external magnetic fields, and a superior temperature compensation circuit.

### Features

- Taut-band suspension system eliminates friction and provides strong resistance to shock impact.
- Stable performance ensures that changes over time are negligible.
- Quick response and easy-to-read scale
- Superior temperature compensation circuit reduces external temperature effects.
- Magnetic circuit (sandwich mechanism) reduces the effects of external magnetic fields.



2011 33



2012 00

### Specifications

Operating principle : Permanent moving coil  
 Class : JIS C 1102: 1997 Class 0.5 (\* equivalent to Class 1.0)  
 Operating position : Horizontal  
 Scale length : Approximately 135 mm (deflection angle: 85°)  
 Scale divisions : 100/150  
 Linemax : 250 V (Ammeters only)  
 Operating temperature and humidity ranges : 0~40°C, 30~75%RH  
 Storage temperature and humidity ranges : -10~50°C, 25~80%RH


External dimensions and weight:  
 2011 Approximately 197 × 181 × 92 mm, approximately 1.7 kg  
 2012 Approximately 260 × 180 × 120 mm, approximately 2.8 kg  
 Standard accessories : Instruction Manual (1)  
 Shunt cable (2011 41, 2012 00 only)  
 Optional accessories (sold separately) : 2291 01 Carrying case for 2011 (page 10)  
 2292 01 Carrying case for 2012 (page 10)

| Model      | Maximum scale value  | Approximate internal resistance and consumed power   |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|------------|--|--|----------------|----------------|----------------|----------------|------|-------|-----|-------|------|-------|-----|-------|-------|-------|------|-------|-------|-------|------|--------|--------|-------|-------|-------------|--------|-------|--|--|
| 2011       | 31 * 3/10/30/100 $\mu$ A   | 5.1/18.3/7.7/2.5 k $\Omega$  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 32 * 10/30/100/300 $\mu$ A   | 6.8/6.8/2.5/0.88 k $\Omega$  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 33 0.1/0.3/1/3 mA  | 750/750/278/97.5 $\Omega$  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 34 1/3/10/30 mA  | 23/14/4.7/1.6 $\Omega$   |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 35 10/30/100/300 mA  | Voltage drop 50 mV   |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 36 0.1/0.3/1/3 A   |  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 37 1/3/10/30 A   |  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 38 0.3/1/3/10 V  | 1 mA (1000 $\Omega$ /V)  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 39 3/10/30/100 V   |  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
|            | 40 30/100/300/1000 V   |  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 41 (50 mV) | 93 $\Omega$  |  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 42 (1 mA)  | Voltage drop 3 V (1000 $\Omega$ /V)  |  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 2012       | 00<br>3/10/30/100/300/1000 V<br>1/3/10/30/100/300 mA<br>1/3/10/30 A/50 mV<br>(17 different measurement ranges) | Voltage measurement range Approximately 1 mA (1000 $\Omega$ /V)<br>Current measurement range<br><table border="1"> <thead> <tr> <th>&lt;Range&gt;</th> <th>&lt;Voltage drop&gt;</th> <th>&lt;Range&gt;</th> <th>&lt;Voltage drop&gt;</th> </tr> </thead> <tbody> <tr> <td>1 mA</td> <td>24 mV</td> <td>1 A</td> <td>53 mV</td> </tr> <tr> <td>3 mA</td> <td>41 mV</td> <td>3 A</td> <td>56 mV</td> </tr> <tr> <td>10 mA</td> <td>47 mV</td> <td>10 A</td> <td>75 mV</td> </tr> <tr> <td>30 mA</td> <td>49 mV</td> <td>30 A</td> <td>100 mV</td> </tr> <tr> <td>100 mA</td> <td>50 mV</td> <td>50 mV</td> <td>59 <math>\Omega</math></td> </tr> <tr> <td>300 mA</td> <td>51 mV</td> <td></td> <td></td> </tr> </tbody> </table> | <Range>        | <Voltage drop> | <Range>        | <Voltage drop> | 1 mA | 24 mV | 1 A | 53 mV | 3 mA | 41 mV | 3 A | 56 mV | 10 mA | 47 mV | 10 A | 75 mV | 30 mA | 49 mV | 30 A | 100 mV | 100 mA | 50 mV | 50 mV | 59 $\Omega$ | 300 mA | 51 mV |  |  |
|            |  | <Range>  | <Voltage drop> | <Range>        | <Voltage drop> |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 1 mA       | 24 mV  | 1 A  | 53 mV          |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 3 mA       | 41 mV  | 3 A  | 56 mV          |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 10 mA      | 47 mV  | 10 A   | 75 mV          |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 30 mA      | 49 mV  | 30 A   | 100 mV         |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 100 mA     | 50 mV  | 50 mV  | 59 $\Omega$    |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |
| 300 mA     | 51 mV  |  |                |                |                |                |      |       |     |       |      |       |     |       |       |       |      |       |       |       |      |        |        |       |       |             |        |       |  |  |

### Notes

1. The asterisks indicate models that are not JIS-approved.
2. For ranges higher than 30 A, externally connect a shunt 2215-2217 (page 10) to the 50 mV terminal on 2011 41 (50 mV instrument) or 2012, 2011 41 (50 mV instrument) and 2012 both come with a set of shunt cables (two 1.5-meter cables with 0.025 W resistance). Different cables may be used if the cable resistance is 0.1 W or less.
3. For ranges higher than 1000 V, use 2011 42 (1 mA instrument) or externally connect external multiplier 2222 or 2223 (page 10) to the 1 mA terminal on 2011 or 2012.

### Scale



### ● 2011 41 50 mV instrument and 2011 42 1 mA instrument

The scale for the 50 mV instrument has 100 and 150 divisions. A 50 mV current transformer may be combined with any rated current instrument to read measurements through a simple conversion process. DC scales (single scale or dual scale) are also available by special order.

Scale on 2011 41 50 mV instrument

# Portable AC Ammeters and Voltmeters

# 2013, 2014



Models 2013 and 2014 are moving iron type instruments using a taut-band suspension system. The suspension system provides excellent reproducibility without friction, and good resistance to shock impact. A cap shield mechanism serving to reduce external magnetic fields, a superior temperature compensation circuit, and other components ensure stable performance.

## Features

- Taut-band suspension system eliminates friction and provides good resistance to shock impact.
- Stable performance ensures that changes over time are negligible.
- Magnetic circuit reduces the effects of external magnetic fields.
- Superior temperature compensation circuit reduces external temperature effects.



2013 14



2014 00

## Specifications

Operating principle : Moving iron type  
 Class : JIS C 1102: 1997 Class 0.5  
 Operating position : Horizontal  
 Scale length : Approximately 135 mm (deflection angle: 85°)  
 Operation frequency range : 45~65 Hz  
 Linemax : 250 V  
 Scale divisions : Check the symbols below against the instrument list.  
 A: 100 divisions B: 150 divisions C: 100/150 divisions  
 D: 100/125 divisions E: 120/150 divisions

Operating temperature and humidity ranges : 0~40°C, 30~75%RH  
 Storage temperature and humidity ranges : -10~50°C, 25~80%RH  
 External dimensions and weight :  
 2013 Approximately 197 × 181 × 92 mm, approximately 1.7 kg  
 2014 Approximately 260 × 180 × 120 mm, approximately 4.2 kg  
 Standard accessories : Instruction Manual (1)

Optional accessories (sold separately) : 2291 01 Carrying case for 2013 (page 10)  
 2292 01 Carrying case for 2014 (page 10)

| Model              | Maximum scale value   | Approximate internal resistance and consumed power                 |
|--------------------|---|--|
|                    | (scale divisions)   |  |
| 2013               | 01 20/100 mA A  | 0.3/0.2 VA   |
|                    | 02 50/250 mA D  | 0.5/0.5 VA   |
|                    | 03 100/500 mA A   | 0.5/0.5 VA   |
|                    | 04 0.2/1 A A  | 0.4/0.4 VA   |
|                    | 05 0.5/2.5 A D  | 0.5/0.5 VA   |
|                    | 06 1/5 A A  | 0.6/0.6 VA   |
|                    | 07 2/10 A A   | 0.7/0.7 VA   |
|                    | 08 5/25 A D   | 1/1 VA   |
|                    | 09 10/50 A A  | 1.2/1.8 VA   |
|                    | 10 20/50/100/200 mA A   | 0.4/0.3/0.2/0.3 VA   |
|                    | 11 0.1/0.2/0.5/1 A A  | 0.2/0.3/0.4/0.5 VA   |
|                    | 12 0.5/1/2/5 A A  | 0.7/0.6/0.5/0.3 VA   |
|                    | 13 2/5/10/20 A A  | 0.5/0.3/0.6/0.9 VA   |
|                    | 14 10/20/50/100 A A   | 0.6/0.9/1.7/2.4 VA   |
| 15 15/30 V B       | 3.8 VA  |  |
| 16 30/75 V B       |   |  |
| 17 75/150 V B      |   |  |
| 18 150/300 V B     |   |  |
| 19 300/750 V B     |   |  |
| 20 (5 A) C         | 0.2 VA  |  |
| 21 (150 V) C       | 3.8 VA  |  |
| 22 500 A (500 A) D | Used in combination with current transformer 2244 (accessory)       |  |
| 2013 (for 400 Hz)  | 23 0.5/1/2/5 A A  | 1.2 VA   |
|                    | 24 2/5/10/20 A A  | 3.5 VA   |
|                    | 25 10/20/50/100 A A   | 3.5 VA   |
|                    | 26 75/150 V B   | 3.8 VA   |
| 27 150/300 V B     | 3.8 VA  |  |
| 2014 00            | 30/75/150/300/750 V   | Each voltage measurement range 4.5 VA<br>Current measurement range |
|                    | 0.15/0.3/0.75/1.5/3/7.5/15/30 A (13 different measurement ranges) B |  |

## Notes

1. For ranges higher than 100 A, externally connect current transformer 2241 or 2242 (page 9) to the 5 A terminal on 2013 20 (5 A instrument) or 2013, or the 7.5 A terminal on 2014.
2. For ranges higher than 750 V, use to 2013 21 (150 V instrument), or externally connect voltage transformer 2261 or 2262 (page 9) to the 150 V terminal on 2013 or 2014.
3. The scales on 2013 20 (5 A instrument) and 2013 21 (150 V instrument) are dual scale (100 and 150) with both scales printed. These standard scales are easy to use through a simple conversion process with CTs and VTs of any rating. DC scales (single scale or dual scale) are also available by special order.

# Portable High-frequency AC Ammeters and Voltmeters, Portable Audio-Frequency Voltmeters

Portable High-frequency  
AC Ammeters and Voltmeters

# 2016

Portable Audio-Frequency  
Voltmeters

# 2017

Model 2016 consists of thermocouple type ammeters and voltmeters with four different measurement ranges. They are designed to provide true RMS values of inputs, so they can be used to measure high-frequency currents and voltages (DC) up to several MHz (the maximum frequency for the voltmeter is 100 kHz). The indicator is based on a taut-band suspension system, which eliminates friction, provides good resistance to vibrations and shock impact, and ensures excellent characteristics.

Model 2017 is a rectifier type, Class 0.5 voltmeter designed for the audio-frequency range.



2016 03 (ammeter)



2017 30

## Features

- Taut-band suspension system eliminates friction and provides good resistance to shock impact.
- 2016: For measurements (DC) up to high frequencies
- 2017: For measurements from 45 Hz to 10 kHz with 1000  $\Omega/V$  internal resistance

## Specifications

### 2016

Operating principle : Thermocouple type  
 Class : JIS C 1102: 1997  
 2016 01~03 : Equivalent to Class 1.0  
 2016 04 : Equivalent to Class 0.5  
 Operating position : Horizontal  
 Scale length : Approximately 135 mm (deflection angle: 85°)  
 Scale divisions : 100 for ammeters, 150 for voltmeter  
 Overload : Approximately 1.5 times rated current (or approximate consumed current)  
 Frequency ranges : 2016 01; DC, 10 Hz to 5 MHz  
 2016 02; DC, 10 Hz to 2 MHz  
 2016 03; DC, 10 Hz to 1 MHz  
 2016 04; DC, 10 Hz to 100 kHz  
 Operating temperature and humidity ranges : 0~40°C, 30~75%RH  
 Storage temperature and humidity ranges : -10~50°C, 25~80%RH  
 Linemax : 250 V (Ammeters only)  
 External dimensions and weight:  
 2016 01~03 Approximately 260×180×141 mm, approximately 2.5 kg  
 2016 04 Approximately 197×181×92 mm, approximately 1.8 kg  
 Standard accessory: Instruction Manual (1)  
 Optional accessories (sold separately): 2291 01 Carrying case for ammeters (page 10)  
 2292 01 Carrying case for voltmeter (page 10)  
 B9646BB Spare thermocouple

### 2017 30

Operating principle : Rectifier type  
 Class : JIS C 1102: 1997, equivalent to Class 0.5  
 Operating position : Horizontal  
 Scale length : Approximately 135 mm (deflection angle: 85°)  
 Scale divisions : 150  
 Maximum scale value : 30/75/150/300 V  
 Rated accuracy :  $\pm 0.5\%$  between 45 Hz and 10 kHz  
 Approximate consumed current : 1 mA (1000  $\Omega/V$ )  
 Operating temperature and humidity ranges : 0~40°C, 30~75%RH  
 Storage temperature and humidity ranges : -10~50°C, 25~80%RH  
 External dimensions and weight : 197×181×92 mm, approximately 1.8 kg  
 Optional accessories (sold separately) : 2291 01 Carrying case (page 10)

### Notes

1. May also be used as an Epstein testing magnetic flux voltmeter.
2. Not JIS-approved.



| Model | Maximum scale value    | Approximate consumed current                   |
|-------|------------------------|--|
| 2016  | 01 5/10/20/50 mA       | Voltage drop: 375 mV<br>5 mA (200 $\Omega/V$ ) |
|       | 02 20/50/100/200 mA    |  |
|       | 03 100/200/500/1000 mA |  |
|       | 04 15/30/75/150 V      |  |

### Notes

1. During measurements, do not allow the current to reach or exceed 1.5 times the rated current or consumed current.
2. If the thermocouple is accidentally burned, it can be easily replaced if you purchase a spare thermocouple. Note, however, that replacing the thermocouple changes the tolerance as follows: 2016 01~03: Class 1.5 2016 04: Class 1.0
3. Ammeters are enclosed in a full shield case, and are connected to the  $\pm$  terminal. A milliamper terminal must be connected to the load in order to measure high-frequency currents.
4. Not JIS-approved.

## Characteristics

### 2016 frequency characteristics (examples)



# Portable Needle-indicator Frequency Meters

## 2038

Model 2038 uses a transducer to convert a measured frequency to a proportionate DC current, then shows the current as a DC current reading. The transducer, combined with a high sensitivity moving coil type indicator based on YOKOGAWA's proprietary taut-band suspension system, provides a level of performance not possible with conventional frequency meters. In addition to frequency measurements for research labs and schools, the 2038 can be used as a standard for measurement control labs and field tests.

### Features

- A wide range of frequencies (45~500 Hz) can be measured with the broad selection of models.
- True equivalent scale enables measurement of continuous frequency changes.
- A wide range of voltages (50~300 V) can be used.
- RMS response (differential system) minimizes waveform effects.
- Anti-shock structure provided by taut-band design.



2038 31

### Specifications

Operating principle : Needle-indicator frequency meter (differential system)  
 Class : JIS C 1102: 1997 (see table below)  
 Operating position : Horizontal  
 Rated voltages : 120/240, 120 V ... Can be used between 50 and 135 V.  
 240 V ... Can be used between 130 and 300 V.  
 Scale length : Approximately 135 mm (deflection angle: 85°)  
 Consumed power : 120 V ... Approximately 1.3 VA 240 V ... Approximately 2 VA



Operating temperature and humidity ranges : 0~40°C, 30~75%RH  
 Storage temperature and humidity ranges : -10~50°C, 25~80%RH  
 Insulating resistance :  
 Minimum 500 V DC 100 MΩ (across electrical circuitry and casing)  
 Withstand voltage : 2000 V AC for 1 minute (across electrical circuitry and casing)  
 External dimensions and weight : 197 × 181 × 92 mm, approximately 1.8 kg  
 Standard accessory : Instruction Manual (1)  
 Optional accessories (sold separately) : 2291 01 Carrying case (page 10)

| Model | Measurement range | Class        | Scale divisions                                       |
|-------|-------------------|--------------|---|
| 2038  | 31                | 45 ~ 65 Hz   | Equivalent to Class 0.2<br>100 divisions (0.2 Hz/div) |
|       | 32                | 20 ~ 100 Hz  | Equivalent to Class 1.0<br>80 divisions ( 1 Hz/div)   |
|       | 03                | 100 ~ 300 Hz | Equivalent to Class 0.5<br>100 divisions ( 2 Hz/div)  |
|       | 04                | 300 ~ 500 Hz | Equivalent to Class 0.5<br>100 divisions ( 2 Hz/div)  |
|       | 11                | 45 ~ 55 Hz   | Equivalent to Class 0.2<br>100 divisions (0.1 Hz/div) |
|       | 12                | 55 ~ 65 Hz   | Equivalent to Class 0.2<br>100 divisions (0.1 Hz/div) |

#### Notes

1. If the voltage exceeds 300 V, externally connect an instrument voltage transformer 2261 or 2262 (page 9).
2. Not JIS-approved.

### Scale



(Note: Frequencies from 0 to 20 Hz are outside the measurement range.)

# Portable Power Factor Meters

# 2039

Model 2039 is a revolutionary series of portable wattmeters in which a power factor is used to operate the DC indicator. This is done using a transducer which provides a DC current proportionate to the voltage-current phase by means of a circuit. Model 2039 can be used in single-phase and balanced three-phase circuits. The electronic transducer, combined with a high sensitivity moving coil type indicator based on YOKOGAWA's proprietary taut-band suspension system, provides a level of performance not possible with conventional power factor meters.

## Features

- For both single-phase and three-phase (balanced circuit).
- Excellent current characteristic: 20~200% of rated current (short time period)
- Wide range of applicable voltages: 60~300 V AC
- Phase angle scale included
- Taut-band suspension system eliminates friction and provides strong resistance to shock impact.



2039 02

## Specifications

Operating principle : Rectifier type  
 Class : JIS C 1102: 1997, equivalent to Class 3.0  
 Operating position : Horizontal  
 Rated frequency : 45~65 Hz  
 Scale length : Approximately 135 mm (deflection angle: 85°)  
 Scale : Lead 0-0.3 to 1.0 to 0.3-0 lag (with phase angle scale)  
 Effective measurement range: Lead 0.5 to 1.0 to 0.5 lag

Consumed power Voltage circuit (120 V) : Approximately 0.14 VA  
 Current circuit (5 A) : Approximately 2.4 VA  
 Operating temperature and humidity ranges : 0~40°C, 30~75%RH  
 Storage temperature and humidity ranges : -10~50°C, 25~80%RH  
 External dimensions and weight :  
 Approximately 260 × 180 × 141 mm, approximately 2.9 kg  
 Standard accessory : Instruction Manual (1)  
 Optional accessories (sold separately) : 2292 01 Carrying case (page 10)



| Model | Rated current | Rated voltage |
|-------|---------------|---------------|
| 2039  | 01            | 0.2/1 A       |
|       | 02            | 1/5 A         |
|       | 03            | 5/25 A        |

120 V  
(Can be used between 60 and 300 V.)



### Notes

1. For measurements exceeding the rated current (25 A), externally connect a current transformer 2241-2243 (page 9) to the 5 A terminal.
2. For measurement with a voltage exceeding 300 V, externally connect a voltage transformer 2261 or 2262 to the 120 V terminal. (page 9)
3. 2039 is not JIS-approved.

## Characteristics



## Connection diagrams



## Portable Wattmeters

# 2041 and 2042



Model 2041 single-phase wattmeters and single-phase low-power-factor wattmeters and Model 2042 three-phase wattmeters are electro-dynamometer type wattmeters with indicators based on taut-band suspension. They can handle DC and frequencies from 25 Hz to 1000 Hz, and provide excellent power factor characteristics. These instruments are shielded with dual permalloy sheets as protection against external magnetic fields.



2041 02



2042 02

### Features

- Frequency range: DC, 25 Hz to 1000 Hz (2041 01-03, 2042 01-03)
- Effective for measurement of low-power-factor load power and small power (2041 11-13, 21, 22)
- Low self-consuming power
- Taut-band suspension system eliminates friction and provides strong resistance to shock impact.

### Specifications

Operating principle : Electro-dynamometer type  
 Operating position : Horizontal  
 Scale length : Approximately 135 mm (deflection angle: 85°)  
 Scale divisions : 120  
 Operating temperature and humidity ranges : 0-40°C, 30-75%RH  
 Storage temperature and humidity ranges : -10-50°C, 25-80%RH

External dimensions and weight :  
 2041 Approximately 260 × 180 × 136 mm, Approximately 2.8 kg  
 2042 Approximately 260 × 180 × 136 mm, Approximately 3.2 kg  
 Standard accessory : Instruction Manual (1)  
 Optional accessories (sold separately) : 2292 01 Carrying case (page 10)

| Product/<br>model                                | Single-phase wattmeter    |                         |                          |
|--|---------------------------|-------------------------|--------------------------|
|  | 2041                      |                         |                          |
|  | 01                        | 02                      | 03                       |
| Parameter  | Three-phase wattmeter     |                         |                          |
|  | 2042                      |                         |                          |
|  | 01                        | 02                      | 03                       |
| Class  | JIS C 1102:1997 Class 0.5 |                         |                          |
| Rated voltage<br>(approximate<br>consumed power) | 120/240 V<br>(1.2/2.4 VA) |                         |                          |
| Rated current<br>(approximate<br>consumed power) | 0.2/1 A<br>(0.66/0.56 VA) | 1/5 A<br>(0.93/0.84 VA) | 5/25 A<br>(1.72/1.69 VA) |
| Rated power factor                               | 1.0                       |                         |                          |
| Operating frequency                              | DC, 25-1000 Hz            |                         |                          |


| Product/<br>model                                | Single-phase low-power-factor<br>wattmeter (Note 5) |                       |                         |                           |                       |
|--|---|-----------------------|-------------------------|---------------------------|-----------------------|
|  | 2041  |                       |                         |                           |                       |
| Parameter  | 11  | 12                    | 13                      | 21                        | 22                    |
| Class  | JIS C 1102:1997 equivalent to Class 0.5             |                       |                         |                           |                       |
| Rated voltage<br>(approximate<br>consumed power) | 120/240 V<br>(2.4/4.8 VA)                           |                       | 30/60 V<br>(0.6/1.2 VA) |                           |                       |
| Rated current<br>(approximate<br>consumed power) | 0.2/1 A<br>(1.25/1.09 VA)                           | 1/5 A<br>(1.7/1.5 VA) | 5/25 A<br>(2.62/2.5 VA) | 0.2/1 A<br>(1.25/1.09 VA) | 1/5 A<br>(1.7/1.5 VA) |
| Rated power factor                               | 0.2   |                       |                         |                           |                       |
| Operating frequency                              | 25-1000 Hz  |                       |                         |                           |                       |

### Notes


1. For measurements exceeding the rated current (25 A), externally connect a current transformer 2241-2243 (page 9) to the 5 A terminal (two required for three-phase).
2. If the rated voltage (240 V) is exceeded, externally connect an instrument voltage transformer 2261 or 2262 (page 9) (two required for three-phase).
3. The low-power-factor wattmeter is used with Epstein test sets, as well as for measurement of low-power-factor power and small power.
4. Three-phase wattmeter total consumed power = (voltage range + current range) × 2
5. Single-phase low-power factor wattmeters are not JIS-approved.

### Characteristics

#### Frequency characteristic (examples)



### Connection diagrams



## Miniature Portable Ammeters and Voltmeters

# 2051, 2052, 2053



The E series of miniature portable instruments consists of JIS C 1102-2 Class 1.0 and Class 1.5 instruments. The taut-band suspension system is used in the moving parts of Models 2051 and 2052 to eliminate friction and provide strong resistance to shock impact.

These instruments are functional and compact, making them suitable for labs at research centers and schools. They are also very useful for factory setups in which numerous instruments are arranged on a small tabletop area, and they are small enough to be carried for maintenance service use.

### Features

- Useful for both high-sensitivity and large-volume measurements  
DC: 30  $\mu$ A~30 A, 0.3 V~300 V  
AC: 500  $\mu$ A~25 A, 3 V~300 V
- Taut-band suspension system eliminates friction and provides strong resistance to shock impact.
- Small and lightweight, with easy-to-read mirrored scale



| Measurement ranges |  |
|--------------------|--|
| DC                 | Current → 30 $\mu$ A 30 A<br>2051 01 to 04 |
|                    | Voltage → 0.3 V 300 V<br>2051 05, 06       |
| AC                 | Current → 0.5 mA 0.25 A 25A<br>2052 2053   |
|                    | Voltage → 3 V 15 V 300 V<br>2052 2053      |

### Specifications

Operating principle : 2051 Permanent magnet moving coil type  
2052 Rectifier type (approximating RMS rectifier type for 15~300 V)  
2053 Moving iron type

Class : JIS C 1102: 1997  
2051... Class 1.0, 2052, 2053... Class 1.5

Scale length : Approximately 88 mm (deflection angle: 90°)

Needle : Bladed needle (red)

Operating position : Horizontal

Linemax : 250 V (Ammeters only)

Operating temperature and humidity ranges : 0~40°C, 30~75%RH

Storage temperature and humidity ranges : -10~50°C, 25~80%RH

External dimensions and weight :  
Approximately 113 × 106 × 46 mm Approximately 0.35 kg

Optional accessories (sold separately):  
2291 02 Carrying case for E series of miniature portable instruments  
A case (B9604WM) that can hold the instrument as well as leads and other accessories is also available. (page 10)

#### Single deflecting meter

| Model | Maximum scale value |                       |            | Approximate internal resistance, consumed power |                                |
|-------|---------------------|-----------------------|------------|---|--------------------------------|
| 2051  | 01                  | 30//100/300/1000/3000 | $\mu$ A DC | 5/6.8/2.8/0.9/0.3                               | k $\Omega$                     |
|       | 02                  | 0.3/1/3/10/30         | mA DC      | 970/390/140/43/14                               | $\Omega$                       |
|       | 03                  | 10/30/100/300/1000    | mA DC      | 4/1.4/0.4/0.14/0.04                             | $\Omega$                       |
|       | 04                  | 0.3/1/3/10/30         | A DC       | 0.14/0.04/0.014/0.004/0.001                     | $\Omega$                       |
|       | 05                  | 0.3/1/3/10/30         | V DC       |   |                                |
|       | 06                  | 3/10/30/100/300       | V DC       |   | 100 $\mu$ A (10 k $\Omega$ /V) |
| 2052  | 01                  | 0.5/1/2.5             | mA AC      |   | 3 V                            |
|       | 02                  | 2.5/5/10              | mA AC      |   |                                |
|       | 03                  | 10/25/50              | mA AC      |   |                                |
|       | 04                  | 50/100/250            | mA AC      |   | 1 mA                           |
|       | 05                  | 3/7.5/15              | V AC       |   |                                |
|       | 06                  | 15/30/75              | V AC       |   |                                |
|       | 07                  | 75/150/300            | V AC       |   |                                |
| 2053  | 01                  | 0.25/0.5/1            | A AC       | 1/1/1   | VA                             |
|       | 02                  | 1/2.5/5               | A AC       | 0.9/0.8/0.7                                     | VA                             |
|       | 03                  | 5/10/25               | A AC       | 0.6/0.9/2.3                                     | VA                             |

#### Zero-Centimeter

| Model | Maximum scale value |                          |       | Approximate internal resistance, consumed power |          |
|-------|---------------------|--------------------------|-------|---|----------|
| 2051  | 11                  | $\pm$ 0.15/0.5/1.5/5/15  | mA DC | 970/390/140/43/14                               | $\Omega$ |
|       | 12                  | $\pm$ 0.3/1/3/10/30      | mA DC | 1170/400/135/40/14                              | $\Omega$ |
|       | 13                  | $\pm$ 5/15/50/150/500    | mA DC | 4/1.4/0.4/0.14/0.04                             | $\Omega$ |
|       | 14                  | $\pm$ 10/30/100/300/1000 | mA DC | 4/1.5/0.4/0.15/0.04                             | $\Omega$ |
|       | 15                  | $\pm$ 0.15/0.5/1.5/5/15  | A DC  | 0.14/0.04/0.014/0.004/0.001                     | $\Omega$ |
|       | 16                  | $\pm$ 0.3/1/3/10/30      | A DC  | 0.15/0.14/0.11/0.004/0.001                      | $\Omega$ |
|       | 17                  | $\pm$ 0.15/0.5/1.5/5/15  | V DC  | 100 $\mu$ A (20 k $\Omega$ /V)                  |          |
|       | 18                  | $\pm$ 0.3/1/3/10/30      | V DC  | 100 $\mu$ A (10 k $\Omega$ /V)                  |          |
|       | 19                  | $\pm$ 1.5/5/15/50/150    | V DC  | 100 $\mu$ A (20 k $\Omega$ /V)                  |          |
|       | 20                  | $\pm$ 3/10/30/100/300    | V DC  | 100 $\mu$ A (10 k $\Omega$ /V)                  |          |

## Instrument Transformers

# 2241, 2242, 2243, 2261, 2262

Instrument transformer is a general term for voltage transformers and current transformers that are used with electrical instruments. The main purpose of instrument transformers is to extend the measurement range for electrical quantities (voltage, current, power, power factor) on large-current and high-voltage circuits. They serve to convert currents and voltages to levels that are suitable for measurement, and to insulate the instrument, etc. from high-voltage circuitry.

YOKOGAWA makes a variety of standard instrument transformers. These include the top class (Class 0.1) current transformer **2243**, the Class 0.2 6600 V circuit instrument voltage transformer **2262**, the 6600 V current transformer **2242**, instrument voltage transformer **2261**, and current transformer **2241**.



### Features

- Precision conversion of electrical quantities on AC large-current or high-voltage circuits
- Secondary circuit is isolated from primary circuit.
- Capable of wide-range measurement using numerous ranges
  - Current : 0.5 A~1500 A
  - Voltage : 15 V~6600 V
  - Relative error :  $\pm 0.1$  to  $\pm 0.2\%$

### Specifications

#### JIS C 1731 Instrument transformers

| Parameter                             | Instrument current transformer                 |  |  | Instrument voltage transformer   |                  |                       |                              |
|---------------------------------------|--|--|--|----------------------------------|------------------|-----------------------|------------------------------|
|                                       | 2241 00  | 2242 00  | 2243 00  | 2261                             |                  |                       | 2262 00                      |
|                                       |  |  |  | 01                               | 02               | 03                    |                              |
| Primary                               | 10/15/30/50/100/<br>250/300/500/750/<br>1500 A | 10/15/30/50/100/<br>250/300/500/750/<br>1500 A | 0.5/0.75/1/1.5/2/<br>3/5/7.5/10/15/20/<br>30/50/75/100 A | 220/440/2200/<br>3300 V          | 15/30/50/75 V    | 100/200/300/<br>500 V | 3300/6600 V                  |
| Secondary                             | 5 A  | 5 A  | 5 A  | 110 V                            | 150 V            | 150 V                 | 110 V                        |
| Rated load                            | 15 VA  | 15 VA  | 15 VA  | 15 VA                            | 15 VA            | 15 VA                 | 15 VA                        |
| Relative error                        | $\pm 0.2\%$                                    | $\pm 0.2\%$                                    | $\pm 0.1\%$  | $\pm 0.2\%$                      | $\pm 0.2\%$      | $\pm 0.2\%$           | $\pm 0.2\%$                  |
| Phase angle                           | $\pm 10$ minutes                               | $\pm 10$ minutes                               | $\pm 5$ minutes  | $\pm 10$ minutes                 | $\pm 10$ minutes | $\pm 10$ minutes      | $\pm 10$ minutes             |
| Class                                 | 0.2  | 0.2  | 0.1  | 0.2                              | 0.2              | 0.2                   | 0.2                          |
| Maximum circuit voltage               | 3450 V   | 6900 V   | 250 V  | –                                | –                | –                     | –                            |
| Withstand voltage<br>(for one minute) | 10000 V  | 16000 V  | 2000 V   | 10000 V                          | 2000 V           | 4000 V                | 16000 V                      |
| Rated frequency                       | 50~60 Hz                                       |  |  | 50~60 Hz                         |                  |                       |                              |
| External dimensions                   | Approximately 318×272×128 mm                   | Approximately 348×280×152 mm                   | Approximately 348×280×136 mm                             | Approximately 255 × 266 × 200 mm |                  |                       | Approximately 294×266×200 mm |
| Weight                                | Approximately 9 kg                             | Approximately 11 kg                            | Approximately 12.5 kg                                    | Approximately 18 kg              |                  |                       | Approximately 18 kg          |

#### Notes

1. Current transformers 2241 and 2242 are terminal type for measurements at 100 A and below, and through type at 250 A and above.
2. 2243 is a terminal type transformer.
3. In addition to 2241 through 2243, 2244 is also available. The specifications for this transformer (for current measurements only; cannot be used for power measurements) are 500 A primary, 5 A secondary (one range, through type), 1.5 VA rated load, Class 0.2 and 250 V maximum circuit voltage.

## Shunts and External Multipliers

# Shunts **2215~2217** External Multipliers **2222 and 2223**

### Shunts

Tolerance :  $\pm 0.2\%$   
 Rated voltage drop : 50 mV



2216 (500 A)

| Model | Rating |       |       |
|-------|--------|-------|-------|
| 2215  | 08     | 15 A  | 50 mV |
|       | 09     | 20 A  |       |
|       | 10     | 30 A  |       |
|       | 11     | 50 A  |       |
|       | 12     | 75 A  |       |
|       | 13     | 100 A |       |
|       | 14     | 150 A |       |
|       | 16     | 300 A |       |

| Model | Rating |        |       |
|-------|--------|--------|-------|
| 2216  | 01     | 500 A  | 50 mV |
|       | 02     | 750 A  |       |
|       | 03     | 1000 A |       |
| 2217  | 01     | 1500 A |       |
|       | 02     | 2000 A |       |
|       | 03     | 3000 A |       |
|       | 04     | 5000 A |       |

### External Multipliers

Class : Class 0.2  
 Consumed current : 1 mA



2222 (1.5/3 kV)

| Model | Rating |             |
|-------|--------|-------------|
| 2222  | 01     | 0.75/1.5 kV |
|       | 02     | 1/2 kV      |
|       | 03     | 1.5/3 kV    |
| 2223  | 00     | 3/5 kV      |

## 2291 and 2292 Carrying Cases



2291 01



2292 01



2291 02

| Model | Compatible instruments |   |
|-------|------------------------|---|
| 2291  | 01                     | 2011, 2013, 2016 (voltmeters), 2017, 2038           |
| 2292  | 01                     | 2012, 2014, 2016 (ammeters), 2039, 2041, 2042, 3254 |
| 2291  | 02                     | 2051, 2052, 2053                                    |

● Carrying cases are useful for carrying and storing instruments.

# List of JIS Mark Indications

| Product                              | Model | Specifications           | JIS mark |
|--------------------------------------|-------|--------------------------|----------|
| DC ammeter (4 ranges)                | 2011  | 31 3/10/30/100 $\mu$ A   | None     |
|                                      |       | 32 10/30/100/300 $\mu$ A |          |
|                                      |       | 33 0.1/0.3/1/3 mA        |          |
|                                      |       | 34 1/3/10/30 mA          |          |
|                                      |       | 35 10/30/100/300 mA      |          |
|                                      |       | 36 0.1/0.3/1/3 A         |          |
|                                      |       | 37 1/3/10/30 A           |          |
| DC voltmeter (4 ranges)              | 2011  | 38 0.3/1/3/10 V          | None     |
|                                      |       | 39 3/10/30/100 V         |          |
|                                      |       | 40 30/100/300/1000 V     |          |
| DC ammeter                           | 2012  | 41 (50 mV)               | None     |
| DC voltmeter                         |       | 42 (1 mA)                | None     |
| DC ammeter and voltmeter             | 2012  | 00 17 ranges             | None     |
| AC ammeter (2 ranges)                | 2013  | 01 20/100 mA             | None     |
|                                      |       | 02 50/250 mA             |          |
|                                      |       | 03 100/500 mA            |          |
|                                      |       | 04 0.2/1 A               |          |
|                                      |       | 05 0.5/2.5 A             |          |
|                                      |       | 06 1/5 A                 |          |
|                                      |       | 07 2/10 A                |          |
|                                      |       | 08 5/25 A                |          |
|                                      |       | 09 10/50 A               |          |
| AC ammeter (4 ranges)                | 2013  | 10 20/50/100/200 mA      | None     |
|                                      |       | 11 0.1/0.2/0.5/1 A       |          |
|                                      |       | 12 0.5/1/2/5 A           |          |
|                                      |       | 13 2/5/10/20 A           |          |
| AV voltmeter (2 ranges)              | 2013  | 14 10/20/50/100 A        | None     |
|                                      |       | 15 15/30 V               |          |
|                                      |       | 16 30/75 V               |          |
|                                      |       | 17 75/150 V              |          |
|                                      |       | 18 150/300 V             |          |
| AC ammeter                           | 2013  | 19 300/750 V             | None     |
|                                      |       | 20 (5 A)                 |          |
| AC voltmeter                         | 2013  | 21 (150 V)               | None     |
| AC ammeter                           | 2013  | 22 500 (500A) A          | None     |
| AC voltmeter (4 ranges) (for 400 Hz) | 2013  | 23 0.5/1/2/5 A           | None     |
|                                      |       | 24 2/5/10/20 A           |          |
|                                      |       | 25 10/20/50/100 A        |          |
| AC voltmeter (2 ranges) (for 400 Hz) | 2013  | 26 75/150 V              | None     |
|                                      |       | 27 150/300 V             |          |
| AC ammeter and voltmeter             | 2014  | 00 13 ranges             | None     |
| High-frequency AC ammeter            | 2016  | 01 5/10/20/50 mA         | None     |
|                                      |       | 02 20/50/100/200 mA      |          |
|                                      |       | 03 100/200/500/1000 mA   |          |
| High-frequency AC voltmeter          | 2016  | 04 15/30/75/150 V        | None     |
| Audio-frequency voltmeter            | 2017  | 30 30/75/150/300 V       | None     |

| Product                                 | Model | Specifications                         | JIS mark |      |                  |      |
|---|-------|--|----------|------|------------------|------|
| Needle-indicator frequency meter        | 2038  | 31 45 ~ 65 Hz 120/240 V                | None     |      |                  |      |
|   |       | 32 20 ~ 100 Hz 120/240 V               |          |      |                  |      |
|   |       | 03 100 ~ 300 Hz 120/240 V              |          |      |                  |      |
|   |       | 04 300 ~ 500 Hz 120/240 V              |          |      |                  |      |
|   |       | 11 45 ~ 55 Hz 120/240 V                |          |      |                  |      |
|   |       | 12 55 ~ 65 Hz 120/240 V                |          |      |                  |      |
| Power factor meter                      | 2039  | 01 0.2/1 A 120 V                       | None     |      |                  |      |
|   |       | 02 1/5 A 120 V                         |          |      |                  |      |
|   |       | 03 5/25 A 120 V                        |          |      |                  |      |
| Single-phase wattmeter                  | 2041  | 01 0.2/1 A 120/240 V                   | None     |      |                  |      |
|   |       | 02 1/5 A 120/240 V                     |          |      |                  |      |
|   |       | 03 5/25 A 120/240 V                    |          |      |                  |      |
| Single-phase low power factor wattmeter | 2041  | 11 0.2/1 A 120/240 V Power factor: 0.2 | None     |      |                  |      |
|   |       | 12 1/5 A 120/240 V Power factor: 0.2   |          |      |                  |      |
|   |       | 13 5/25 A 120/240 V Power factor: 0.2  |          |      |                  |      |
|   |       | 21 0.2/1 A 30/60 V Power factor: 0.2   |          |      |                  |      |
|   |       | 22 1/5 A 30/60 V Power factor: 0.2     |          |      |                  |      |
| Three-phase wattmeter                   | 2042  | 01 0.2/1 A 120/240 V                   | None     |      |                  |      |
|   |       | 02 1/5 A 120/240 V                     |          |      |                  |      |
|   |       | 03 5/25A 120/240 V                     |          |      |                  |      |
| Miniature DC ammeter                    | 2051  | 01 30/100/300/1000/3000 $\mu$ A        | None     |      |                  |      |
|   |       | 02 0.3/1/3/10/30 mA                    |          |      |                  |      |
|   |       | 03 10/30/100/300/1000 mA               |          |      |                  |      |
|   |       | 04 0.3/1/3/10/30 A                     |          |      |                  |      |
|   |       | 11 $\pm$ 0.15/0.5/1.5/5/15 mA          |          |      |                  |      |
|   |       | 12 $\pm$ 0.3/1/3/10/30 mA              |          |      |                  |      |
|   |       | 13 $\pm$ 5/15/50/150/500 mA            |          |      |                  |      |
|   |       | 14 $\pm$ 10/30/100/300/1000 mA         |          |      |                  |      |
|   |       | 15 $\pm$ 0.15/0.5/1.5/5/15 A           |          |      |                  |      |
|   |       | 16 $\pm$ 0.3/1/3/10/30 A               |          |      |                  |      |
| Miniature DC voltmeter                  | 2051  | 05 0.3/1/3/10/30 V                     | None     |      |                  |      |
|   |       | 06 3/10/30/100/300 V                   |          |      |                  |      |
|   |       | 17 $\pm$ 0.15/0.5/1.5/5/15 V           |          |      |                  |      |
|   |       | 18 $\pm$ 0.3/1/3/10/30 V               |          |      |                  |      |
|   |       | 19 $\pm$ 1.5/5/15/50/150 V             |          |      |                  |      |
|   |       | 20 $\pm$ 3/10/30/100/300 V             |          |      |                  |      |
|   |       | Miniature AC ammeter                   |          | 2052 | 01 0.5/1/2.5 mA  | None |
|   |       |  |          |      | 02 2.5/5/10 mA   |      |
|   |       |  |          |      | 03 10/25/50 mA   |      |
|   |       |  |          |      | 04 50/100/250 mA |      |
| Miniature AC voltmeter                  | 2052  | 05 3/7.5/15 V                          | None     |      |                  |      |
|   |       | 06 15/30/75 V                          |          |      |                  |      |
|   |       | 07 75/150/300 V                        |          |      |                  |      |
| Miniature AC ammeter                    | 2053  | 01 0.25/0.5/1 A                        | None     |      |                  |      |
|   |       | 02 1/2.5/5 A                           |          |      |                  |      |
|   |       | 03 5/10/25 A                           |          |      |                  |      |

# Q & A

## Is there a way to use the portable instruments in an upright (vertical) position?

Portable instruments must be used in a horizontal position (standard position). There is no assurance of precision within the specified ranges if a portable instrument is set in a vertical or tilted position during use. This is due to the weight balance of the moving parts, including the indicator needle. If the instrument is horizontal, there is basically no balance problem, but if it is vertical, the indicator error will be doubled. There are no strict guidelines on leveling the instrument (e.g., using a spirit level). It should be OK if it is set on a desk (or bench) that is basically level. If you really need to use your portable instrument in a vertical position, you should calibrate it in that position before use.

## Can I order measurement leads from YOKOGAWA

YOKOGAWA does not carry measurement leads; you will need to purchase them separately. We do not carry leads because it is very difficult to establish a standard type of lead. This is because, with the exception of chips connected on the instrument end, line diameters, lengths, and the specifications of the remote chip being connected can vary greatly, depending on operating conditions. However, shunt cables (two 1.5-meter cables with  $0.05\Omega$  resistance) are provided with external shunt ammeters 2011 14 (50 mV) and 2012 00.

## What are Class 0.5 and Class 1.0?

They are precision classes specified in JIS C 1102: 1997 (“Direct Acting Indicator Electrical Instruments”). The classes refer specifically to limitations on error and influential fluctuations (characteristics), but are normally used to indicate the maximum tolerance.

Class 0.5 =  $\pm 0.5\%$  of fiducial value; percentage of range’s maximum scale value


Class 1.0 =  $\pm 1.0\%$  of fiducial value; percentage of range’s maximum scale value

## What is the solid circle (●) above the scale number on the labels of Models 2013 and 2014?

This indicates the minimum value in the measurement range.

- The range from the scale value marked by the solid circle to the maximum scale value is the guaranteed precision range.
- Values below the scale value marked by the solid circle are outside the guaranteed precision range.

This mark is specified in JIS C 1102:1997 (“Direct Acting Indicator Electrical Instruments”).



## What is the maximum circuit voltage of the ammeters?

250 V (called the nominal circuit voltage in JIS C 1102:1997).

The applicable ammeter models are 2011, 2012, 2013, 2014, 2016, 2051, 2052, and 2053.

## What are the test voltages for the voltage tests on the various meters?

The test voltages are listed below. Tests are done across the input terminal (electric circuit) and the outer casing.

3000 V AC for one minute; 2011, 2012, 2013, 2014

2000 V AC for one minute; 2016, 2017, 2051, 2052, 2053, 2038, 2039, 2041, 2042

## How do you calculate the internal (terminal-to-terminal) resistance or impedance?


When voltage drop is given on an ammeter; Voltage drop (V)/Range’s rated current (A) = Internal resistance

When consumed current is given on a voltmeter; Range’s rated voltage (V)/Consumed current (A) = Internal resistance

When consumed power is given on an ammeter (circuit); Consumed power (VA)/Square of rated current (A) = Internal impedance

When consumed power is given on a voltmeter (circuit); Square of rated voltage (V)/Consumed power (VA) = Internal impedance

(1997) Compliance



New JIS (JIS C 1102-1997) Compliance

**NOTICE**

- Before operating the product, read the instruction manual thoroughly for proper and safe operation.

**YOKOGAWA** 

**YOKOGAWA ELECTRIC CORPORATION**

Meters Business Center Sales Dept./Phone: 81-428-33-3789, Facsimile: 81-428-33-3753

**YOKOGAWA CORPORATION OF AMERICA**

Phone: 1-770-253-7000, Facsimile: 1-770-251-2088

**YOKOGAWA EUROPE B.V.**

Phone: 31-33-4622142, Facsimile: 31-33-4641659

**YOKOGAWA ENGINEERING ASIA PTE. LTD**

Phone: 65-62419933, Facsimile: 65-62412606

Subject to change without notice.

[Ed : 08/b] Copyright ©2000

Printed in Japan: Jun. 2005(C)/1,000(KP)